


What's in the Box



<p>1 Robomow®</p>	<p>6 Operating & Safety Manual</p>	<p>11 Extension Cable 20 meters (65 ft.), (Low voltage cable).</p>
<p>2 Perimeter Wire Used to create a virtual wall for your Robomow.</p>	<p>7 DVD – Setup and Operation Video.</p>	<p>12 Power Box Used to deactivate (halt) the automatic operation mode and reactivate it as needed. Also provides indication of Robomow's status (Docking or Operating) and the Perimeter Wire's health.</p>
<p>3 Pegs Used for securing the wire to the ground.</p>	<p>8 RoboRuler Used for setting the distance of the Perimeter Wire from the lawn edge.</p>	<p>13 Power Box Mount Used for fixing the Power Box to a wall. (including Screws and dowels).</p>
<p>4 Wire Connectors Used for splicing wires (as needed).</p>	<p>9 Assembled Base Station Used by Robomow to dock and charge when it is not mowing.</p>	<p>14 Template Used for installing a Narrow Pass.</p>
<p>5 Plot Connector Used for connecting the Perimeter Wire to the Base Station.</p>	<p>10 Base Station Stakes Used for securing the Base Station to the ground.</p>	<p>15 Remote Control (supplied with RS630 only) Used to manually drive and mow anywhere.</p>